



HONGHUA MUD PUMPS PARTS LIST

Description	F500	F800	F1000	F1300/1600	F1600HL	F2200HL
Liner of Crosshead Upper	AH0501010402	AH0801010402	AH1001010402	AH1301010402	AH1301010402	AH2202010402
Liner of Crosshead Lower		AH0801010408	AH1001010409	AH1301010412	AH1301010412	AH2202010403
Pin of Crosshead	AH0501010404	AH0801010407	AH1001010408	AH1301010410	AH1301010410	AH2202010410
Extension Rod	AH0501010410	AH0801010406	AH1001010407	AH1301010409	AH1301010409	AH2202010409
Crosshead	AH0501010401	AH0801010401	AH1001010401	AH1301010401	AH1301010401	AH2202010401
Pinion Shaft	AH0501010302	AH0801010302	AH1001010302	AH1601010201	AH1601010201	
Wear Ring of Pinion shaft	AH0501010303	AH0801010303	AH1001010303	AH1301010303	AH1301010303	AH2202010306
Carrier, Bearing Left	AH0501010212	AH0801010213	AH1001010212	AH1601010105	AH1601010105	AH2202010212
Carrier, Bearing Right	AH0501010202	AH0801010202	AH1001010202	AH1601010101	AH1601010101	AH2202010202
Connecting Rod	AH0501010206	AH0801010206	AH1001010206	AH1601010103	AH1601010103	AH2202010206
Bull Gear	AH0501010210	AH0801010210	AH1001010219	AH16010101040 0	AH16010101040 0	AH220201021000
Bolt, Main Bearing	AH051020207	AH0801020206	AH1001010215	AH1301010215	AH1301010215	AH2202010215
Bearing, Crosshead	5G354920Q	4G254735Q	5G254936Q	AH1301010414	AH1301010414	
Bearing, Pinion Shanft	4G32828H	4G32836H	4G32840H	AH1301010312	AH1301010312	AH2202010315
Bearing, Eccentric	92984QU	928/508QU	929/558.8QU	AH16010101070 0	AH16010101070 0	AH2202010217
Bearing, Main	3053738U	3053748H	4053156H	AH16010101080 0	AH16010101080 0	AH2202010218